

OPERATING MANUAL - MANUALE D'USO BETRIEBSANLEITUNG - MANUEL DE SERVICE



IRM 312 TS



**32.70.312.5273
Ed. 03/2000**

Plus d'informations sur : www.dbmoteurs.fr

*Thank you
for choosing a*

ZF MARINE gearbox

- ***The purpose of this manual is to provide all the information necessary for proper installation, maintenance and operation of your ZF Marine Gearbox.***

- ***Also included in the manual is maintenance information that will help you obtain long service life from your ZF Marine Gearbox.***

- ***ZF Aftersales Service operates worldwide. The main service centres are listed at the end of the manual.***

© 1999 This manual cannot be copied or reproduced whether wholly or in part, electronically or otherwise, without the written consent of ZF MARINE S.p.A.

Printed in Italy

First published: **30/07/99**

Edition: **03/2000**

Part number: **32.70.312.5273**

[illegible]

CONTENTS

1

General

Page 5

1.1	Manufacturer's address and contact numbers	"	5
1.2	Gearbox data	"	5
1.3	How to use this manual	"	6
1.4	Conventional symbols used in the manual	"	6
1.5	Description of the gearbox	"	7
1.6	Operation	"	8
1.6.1	IRM 312 TS	"	8
1.7	Electrohydraulic control system	"	10
1.7.1	Control box	"	10
1.7.2	Trolling Valve (T.V.)	"	10
1.8	Emergency control	"	11
1.8.1	Electrical system trouble	"	11
1.9	Technical specifications	"	13
1.9.1	Oil types	"	13
1.9.2	Pressures and temperatures	"	13

2

Installation

Page15

2.1	Standard gearbox installation	"	15
2.2	Connection to propeller shaft	"	16
2.3	Installation of control box	"	17
2.3.1	6 core electrical cable	"	17
2.3.2	Connection diagram	"	18

3

Troubleshooting

Page19

3.1	Troubleshooting	"	19
-----	-----------------------	---	----

4

Maintenance

Page23

4.1	Maintenance schedule	"	23
4.2	Routine maintenance operations	"	24
4.2.1	After 50 hours operation	"	24

4.2.2	<i>Daily</i>	"	25
4.2.3	<i>After six months or 250 hours</i>	"	25
4.2.4	<i>Annually or every 500 hours</i>	"	26

5**Warranty** _____ **Page 27**

5.1	<i>Terms and conditions of warranty</i>	"	27
5.2	<i>Service centres</i>	"	28

6**Service history** _____ **Page 31**

CHAPTER 1 GENERAL

1.1 MANUFACTURER'S ADDRESS AND CONTACT NUMBERS

All gearboxes supplied by ZF Padova S.p.A. are accompanied by the relative operating manual. Further copies of this manual or of other technical documentation can be obtained from:

ZF Padova S.p.A.
Ufficio tecnico
Via Penghe 48,
35030 Caselle di Selvazzano PD


Tel. +39 - 0498299589
Fax +39 - 0498299550

1.2 GEARBOX DATA

Identification data plate

Details of the gearbox will be found on the identification data plate:

- Located on the top of the gearcase.

		TYPE	
SERIAL No		RATIO	
PART LIST No	CUSTOMER No	MASS DRY (Kg)	
Pleasure	Light	Medium	Continuous
OIL TYPE	OIL CAPACITY (dm ³)	CLUTCH OIL PRESSURE(bar)	
OIL CHANGE: after first 50 hours of operation and every 1000 hours or 12 months, whichever occurs first.			
CHECK OIL LEVEL WEEKLY			




Fig. 1

1.3

HOW TO USE THIS MANUAL

This manual is intended for use with the corresponding ZF gearbox family as designated on the front cover.

A copy of the manual should be kept in a place where it can be found and consulted without difficulty by persons entrusted with operation and maintenance of the gearbox.



Read this manual carefully before installing the gearbox, as it contains important directions and guidelines.

ZF cannot be held liable for damage to people, property or data caused by incorrect installation, use or maintenance. All operations must be performed in accordance with the instructions given in this manual and other manuals supplied with the gearbox.

All manuals and literature published by ZF Padova are designed for ease of reference so that the operator can find specific information without difficulty.

For further information not included in this or other manuals, consult the ZF Padova technical services department direct.

1.4

CONVENTIONAL SYMBOLS USED IN THE MANUAL

The following symbols and indications are adopted in this manual:

Italics: Used for chapter headings, sub-headings, and in tables or figures or when referencing other publications.



When this symbol is displayed, the text alongside contains important information.



This symbol denotes a procedure that could damage the gearbox or associated equipment if not followed correctly.



This symbol denotes a procedure that could result in physical injury to the operator or to other persons in the vicinity if not followed correctly.

1.5

DESCRIPTION OF THE GEARBOX

The following accessories can be added to the basic specification as required: heat exchanger, flexible drive coupling (torque limiter), mounting brackets.

The gearbox and its accessory equipment are factory set by the manufacturer and require no further




Fig. 2




Fig. 3

Tab. 1

REF	DESCRIPTION	REF	DESCRIPTION
1	PTO cover	10	Oil filler plug
2	Oil pump	11	Control valve
3	Output shaft	12	Solenoid valves
4	Strainer / Oil filter	13	Pressure port 1/8-27 N PTF
5	Drain plugs	14	Pump pressure port M14 x 1.5
6	Rear half housing	15	Oil Filter
7	Front half housing	16	Control box
8	Dipstick and breather	17	Screened cable connector
9	Heat exchanger		

1.6

OPERATION

1.6.1

IRM 312 TS

A marine gearbox has three main functions:

- speed reducer, serving to match the engine and propeller speed to the propulsion requirement;
- reversing gear, allowing ahead/astern selection by way of two hydraulically operated clutches;
- neutral, allowing the engine to run without driving the propeller.


The types of operation possible are illustrated below.

↑ **Power transmission.**

↑ **Idle rotation, no power transmission**

Neutral


Engine power is transmitted to the input and intermediate shafts only; no power is transmitted to the propeller shaft as all clutches [9-10-11-12] are disengaged.



Engine rotation 1st speed

Obtained by engaging a first clutch [11] on the intermediate shaft (rotating in the opposite direction to the crankshaft).

The first gear [4] on the intermediate shaft is coupled by the clutch [11] and driven by the crankshaft. This gear [4] drives a gear [5] keyed to the output shaft. The speed reduction is determined by the ratio between the two gears [4] and [5].




Engine rotation 2nd speed

Obtained by engaging a second clutch [12] on the intermediate shaft (rotating in the opposite direction to the crankshaft).

The second gear [7] on the intermediate shaft is coupled by the clutch [12] and driven by the crankshaft. This gear [7] drives a gear [8] keyed to the output shaft.

The speed reduction is determined by the ratio between the two gears [7] and [8].



Counter engine rotation 1st speed

Obtained by engaging a first clutch [9] on the input shaft (rotating in the same direction as the crankshaft).

The first gear [3] on the input shaft is coupled by the clutch [9] and driven by the crankshaft. This gear [3] drives a gear [5] keyed to the output shaft.

The speed reduction is determined by the ratio between the two gears [3] and [5].




Fig. 7

Counter engine rotation 2nd speed

Obtained by engaging a second clutch [10] on the input shaft (rotating in the same direction as the crankshaft).

The second gear [6] on the input shaft is coupled by the clutch [10] and driven by the crankshaft.

This gear [6] drives a gear [8] keyed to the output shaft.

The speed reduction is determined by the ratio between the two gears [6] and [8].




Fig. 8

The clutches are operated hydraulically.

Fig. 9 below shows a simple schematic diagram of the hydraulic circuit.




Fig. 9

1.7

HYDRAULIC CONTROL SYSTEM

Marine gearboxes of the 312 family are controlled by an electrohydraulic system including a directional control valve [1] and an electronic control box [2] (see Fig. 10).

The system requires a d.c. power supply of 12 V or 24 V (depending on the solenoid valves fitted).

1.7.1

CONTROL BOX

The control box must not be mounted to the engine or gearbox, or in any position where it could be affected by excessive vibration. Do not locate the box near to engine ignition systems, alternators, electric motors or engine exhaust manifolds.

The preferred location for the control box is normally inside the engine compartment.

If there is not sufficient room in the engine compartment, select a location affording access for connection of the electrical cables.

The electronic control box is connected to the solenoid valves by 5 electrical cables 2 metres each in length.

The box is guaranteed watertight provided that:

- * The screws securing the cover and the cable clamps are all properly tightened.
- * The connector of the 6-core cable is fitted and locked with the retaining lever.
- * The connector of the screened cable is always connected to the base.




Fig. 10

1.7.2

1.7.2 TROLLING VALVE (T.V.)

The trolling valve is a device that permits a variable control of the speed (Fig.11).

It permits to make the propeller work at a lower speed in comparison with the system without T.V.

It's used to reduce the boat speed when the engine is already at idle speed.

The trolling valve system can be used for forward and backward movements, observing the peak rpm indicated below.

Application data

The T.V. can be used only for motors which peak rotating running is higher than 2000 rpm and when the trolling is on, it is possible to modify the revolution number up to 700 rpm.

Use


Reduce the motor revolutions to the minimum, then engage the gear checking that the Trolling Valve has been excluded.

Move the T.V.lever as to obtain the desired speed.

When the trolling is on, it is possible to modify the revolution number up to 700 rpm using the required graduality



It is forbidden manoeuvring (forward - reverse and viceversa) and change of speed when in trolling mode.




1.8

EMERGENCY CONTROL



1.8.1

ELECTRICAL SYSTEM TROUBLE

Should a power failure occur, the gearbox will fail safe by reverting to neutral. In the event of an electrical or solenoid failure, the valves [1] can be operated mechanically, proceeding as follows and with extreme caution: disconnect the cables from all solenoid valves; determine which of the solenoids gives the direction of drive required (indicated normally on a label attached to the relative cable), and remove the cap [2] using a 22mm wrench (Fig. 12). Lift and rotate the button counterclockwise through 90°.



Having completed the operation, ensure that the solenoid valve is positioned as shown in fig. 13. The operation can be performed on valves 1D, 2D, 2C and 1C (Fig. 13A).




Never perform this operation on two or more valves at once, as the relative clutches will engage at the same time and cause the gear-box to lock up.

A = valve closed (normal position);
B = valve open (emergency position)
 (drive selected).



The procedure is the same when locking the gearbox in 2nd speed



Resetting: To reset the solenoid valve, rotate the button clockwise 90°.



Having completed the operation, ensure that the solenoid valve is positioned as shown in fig. 14. Replace and tighten the cap [2] (see fig. 12) using a 22mm wrench, torquing to 2-5 Nm.

In the event of the valve body (see fig. 15) being removed and refitted, use a 26mm wrench and torque to 45 Nm.



Important

All seals must be located in the relative seats.



2.3

INSTALLATION OF CONTROL BOX

The control box is connected to the solenoid valves by way of 5 electrical cables each 2 metres in length, of which the ends are fitted with DIN 43650 connectors.



Important: do not disconnect the terminals from the control box when the engine is running. Isolate the control system from the power supply by means of the control key (Fig. 4) before disconnecting it from the batteries.



Ensure that the solenoid valves fitted are suitable for the voltage of the d.c. power source.

The 5 cables must be connected as in fig. 3.

The bending radius of the 5 cables must be suitably wide (minimum bending radius 50 mm/2").

FO	Neutral
1C	select 1° speed (engine rotation)
2C	select 2° speed (engine rotation)
1D	select 1° speed (counter engine rotation)
2D	select 2° speed (counter engine rotation)




Fig. 3



The connection between the control box and the bridge must be made with a six core screened lead.

2.3.1

6-core electrical cable

The six-core screened cable must be of 10 mm external diameter and have the following specifications:

Non flame propagating	IEC 332-3A - CEI 20-22 II
Resistant to oil	CNOMO E. 03.04.15 ON - NFT 46-D13-UL 1581
Resistant to sea water	CEI 20-34 section II

1.9

TECHNICAL SPECIFICATIONS

1.9.1

OIL TYPE

OIL: all models

Tab. 2



Oil	Specification	Viscosity		v.i.	Specification
SAE 30*	SAE 30	102 cst (40°C)	12 cst (100°C)	100	MIL - L 2104C API classes MIL - L 2104D CC-CD-SC MIL - L 46152 SD-SE-SF
SAE 40**	SAE 40	145 cst (40°C)	14.5 cst (100°C)	99	MIL - L 2104C API classes MIL - L 2104D CC-CD-SC MIL - L 46152 SD-SE-SF

* = recommended

** = alternative for hot countries

Tab. 3



Oil quantity	10 litres
--------------	-----------

- Use the correct grade of oil, poured in through the filler (10 page 7).

Oil pump flow: 15 litres/min at 1000 rpm

1.9.2

PRESSURE AND TEMPERATURE

Tab. 4



OPERATING PRESSURE	23÷24 bar
OPERATING OIL TEMPERATURE	40÷75° C

- Pressure and temperature are measured at port 13 (see illustration on page 7).



IF THE VALUES MEASURED ARE NOT AS EXPECTED, FIRST CHECK THE ACCURACY OF THE INSTRUMENTS. IF STILL IN DOUBT, CONSULT YOUR NEAREST ZF SERVICE CENTRE OR CONTACT ZF PADOVA DIRECT.



The following instrumentation is recommended: a pressure sender (0-50 bar) mounted to the port 13 (Fig. 3 Page 7) on the control valve cover.
A temperature sensor (20-20 °C) fitted to one of the drain outlets 5 (Fig. 2 page7) and a corresponding gauge on the bridge console; the oil temperature should not stray from the normal operating value indicated in table 4.

STANDARD GEARBOX INSTALLATION

Gearboxes of the families covered in this manual are normally flange-mounted to the engine. This ensures concentric alignment between the gearbox input shaft and the crankshaft. The entire engine and transmission assembly can then be mounted resiliently. It is good policy to include a bridging plate between the gearbox mountings and the rear engine mountings, to which the brackets for the resilient mounts are fitted. Gearboxes mounted separately from the engine and coupled by way of a universal joint can be mounted either rigidly or resiliently. The brackets carrying the mounts should be fitted to the gearbox mounting points and braced together to form a U shape, giving added rigidity and strength. For free-standing gearboxes, the connection to the engine must be by way of a flexible coupling. Refer to the following installation drawings for more detail.




Fig. 1



When installing the gearbox, sufficient space must be allowed to ensure access for the purpose of servicing the heat exchanger, oil filter and oil pump and accessing the dipstick.

The oil drain plug must be easily accessible.

Tab. 1

PERMISSIBLE INSTALLATION ANGLES [°] (Referred to perpendicular and longitudinal axes of input shaft relative to horizontal plane)	Static angle	Transient angles	
		Pitch	Roll
	- 5 ... + 10	- 10 ... + 25	- 15 ... + 15

2.2

CONNECTION TO PROPELLER SHAFT

Whilst the gearboxes covered by this manual are fitted with a thrust bearing, it may be necessary to add at least one further thrust bearing to the propeller shaft when axial loads on the transmission are liable to be severe or sustained. Selection of the propeller shaft dimensions and positioning of the bearings are the responsibility of the installer. Axial and radial loads on the propeller shaft impact directly on the gearbox. If there is any concern or doubt regarding connection of the propeller shaft, consult the ZF Marine Design Engineering Department.

Performance data for the propeller shaft bearing will depend on the loads applied during operation, and must be specified by the designer and builder of the craft.



X [mm]
0.05 max



Y [mm]
0.1 max



L [mm]
500 min for $d < 60$ mm
1000 min for d 60 - 90 mm
2000 min for $d > 90$ mm




Fig. 2

It is essential that alignment be carried out before the craft is delivered to the customer, remembering that:

- 1) The boat must be in the water and the hull settled before final alignment of the driveline, as distortion of the hull in water can affect an alignment carried out in dry dock.
- 2) The propeller shaft must have sufficient freedom of movement to allow removal of the flanges.



Misalignment can cause irreparable damage to the gearbox, stern tube seals and bearings, as well as contributing to noise and vibration.

ZF Padova S.p.A. declines any liability under warranty for mechanical failure attributable to improper use or installation.



Important: when commissioning the craft, ensure before starting up the engine that all solenoid valve "manual overrides" are deselected and in the "normal position" (see heading 1.8.1). The "FO" (neutral) solenoid valve has no manual override.

2.3

INSTALLATION OF CONTROL BOX

The control box is connected to the solenoid valves by way of 5 electrical cables each 2 metres in length, of which the ends are fitted with DIN 43650 connectors.



Important: do not disconnect the terminals from the control box when the engine is running. Isolate the control system from the power supply by means of the control key (Fig. 4) before disconnecting it from the batteries.



Ensure that the solenoid valves fitted are suitable for the voltage of the d.c. power source.

The 5 cables must be connected as in fig. 3.

The bending radius of the 5 cables must be suitably wide (minimum bending radius 50 mm/2").

FO	Neutral
1C	select 1° speed (engine rotation)
2C	select 2° speed (engine rotation)
1D	select 1° speed (counter engine rotation)
2D	select 2° speed (counter engine rotation)




Fig. 3



The connection between the control box and the bridge must be made with a six core screened lead.

2.3.1

6-core electrical cable


The six-core screened cable must be of 10 mm external diameter and have the following specifications:

Non flame propagating	IEC 332-3A - CEI 20-22 II
Resistant to oil	CNOMO E. 03.04.15 ON - NFT 46-D13-UL 1581
Resistant to sea water	CEI 20-34 section II

2.3.2

Connection diagram

Make the connections to the terminals of the control box as indicated in the diagram.



The screening of the earth cable must be cut at the end of the sheath.



The diagram is valid for one gearbox installation only.



Caution: the control box must be powered up only when the engine is running. Protect the circuit with a fuse (8.0 M5x20F DIN 41661) located between the power source and the control key, as indicated in the control panel section (connection diagram).



Energizing two engine rotation and counter engine rotation solenoid valves simultaneously has the effect of activating the "FO" neutral valve.

SYMPTOMS	CAUSES	REMEDIES
1) No oil pressure in main and lubrication circuits either in neutral or with drive engaged	1 - No oil in gearcase 2 - Wrong direction of rotation 3 - Suction filter completely clogged 4 - Oil suction lines damaged or disconnected 5 - Oil pump damaged or worn 6 - Oil pump drive coupling failure 7 - Input or intermediate shaft failure 8 - Driveline coupling failure	- Fill with oil * - Check application specifications * - Remove and clean filter * - Remove oil lines and inspect. Replace parts as required * - Replace pump * - Remove pump and replace coupling * - Remove shaft and replace * - Replace coupling
2) Low oil pressure with drive engaged	1 - Pressure control valve stuck in open position 2 - Low oil level 3 - Clutch oil lines leaking (worn clips, damaged sub-plates, faulty piston seals) 4 - Suction filter partially clogged 5 - Oil pump damaged or worn 6 - Pressure control valve seat damaged 7 - Pressure control valve spring worn or broken 8 - Wrong type of oil 9 - High oil temperature 10 - "FO" solenoid valve damaged 11 - Selector Trolling lever not properly set 12 - Trolling control valve lever in trolling mode	- Remove valve and clean thoroughly - Top up to level indicated * - Overhaul gearbox and replace worn parts as necessary - Remove and clean filter * - Replace pump * - Remove valve, strip, and inspect seat * - Inspect spring and replace if worn. Readjust pressure setting - Drain gearbox and fill with correct grade * - See cause 3 * - Replace valve - Adjust remote controls - Put the lever no trolling range

* Operations marked with this symbol should be entrusted to a ZF Authorized Service Centre.

SYMPTOMS	CAUSES	REMEDIES
3) High oil pressure	1 - Pressure control valve stuck in closed position	- Remove valve and clean thoroughly
	2 - Internal oil lines and/or pipelines obstructed	* - Overhaul gearbox and clean oil ways
4) High oil temperature	1 - Heat exchanger too small	* - Replace present heat exchanger with one of suitable capacity
	2 - Insufficient flow of water to heat exchanger	* - Replace valves and pipelines with others of larger internal diameter
	3 - Heat exchanger dirty	* - Clean heat exchanger
	4 - Oil level too high or too low	- Restore normal level
	5 - Wrong type of oil	- Drain gearbox and fill with correct grade
	6 - Clutches slipping	- Check operating pressure
	7 - Cavitation in oil pump	- Add oil and/or inspect suction lines
	8 - Bearings incorrectly preloaded, or damaged	* - Check preload or replace bearings
	9 - Clutch piston seized	* - Remove clutches and overhaul
	10 - Clutch discs warped	* - Overhaul clutches and replace discs
	11 - Insufficient oil flow to the cooler	* - Check oil pump
5) Excessive noise	1 - Cavitation in oil pump	- Tighten all fittings and/or replace damaged pipelines; check filter and O-rings
	2 - Incorrect bearing adjustment (excessive end float)	* - Check bearing end float and correct with shims as necessary
	3 - Bearings damaged	* - Overhaul gearbox and replace damaged parts
	4 - Worn gear teeth	* - Overhaul gearbox and replace worn gears
	5 - Flexible coupling wrong type or damaged	* - Remove coupling and replace with a suitable type
6) No neutral	1 - Clutch discs warped	* - Overhaul gearbox and replace discs
	2 - Clutch piston seized	* - Remove clutch and overhaul

* Operations marked with this symbol should be entrusted to a ZF Authorized Service Centre.

SYMPTOMS	CAUSES	REMEDIES
7) Drive difficult or impossible to engage	1 - Air in hydraulic circuit	- Check oil level. Correct air leaks in pipelines, drain aerated oil and replace with fresh oil
	2 - Clutch piston seized	* - Remove clutch and overhaul
	3 - Pressure modulation system defective	* - Check control valve
	5 - Internal oil leak	- Check oil circuit
	6 - Incorrect oil temperature	- Check heat exchanger and water flow
	7 - Drive difficult or impossible to engage with pressure of ≥ 5 bar	- Check external fuse (near control key) and replace if necessary. - Check that the 6-pin connector is plugged in correctly to the control box (reconnect if not). - Check the integrity of the cable and if damaged use the emergency manual override. Call out an approved service technician. - Check the connections from control box to control panel and viceversa.
	8 - Drive does not engage within acceptable space of time.	- Check that the manual override is in the correct position. - Check that the solenoid valve connector is correctly (and securely) plugged in. - Make certain that defective installation has not resulted in partial oxidation of the electrical contacts at the solenoid valve affected. (Clean contacts, or replace the connector and the solenoid valve as necessary). - have specialist technicians check the neutral overlap time (if fault occurs when reversing direction). - have specialist technicians check the speed selection overlap time.
	9 - When reversing the drive direction (holding neutral for at least 0,5 seconds with pressure registering higher than 15 bar), the gearbox begins to respond jerkily, kicking strongly every time the direction is reversed.	- Check connections, look for oxidation of electrical contacts in the FO solenoid valve control circuit. Replace the solenoid valve or the connector, or both, as necessary. - have specialist technicians check the neutral overlap time.
	10 - During a standard reversing manoeuvre the gearbox begins to respond too slowly.	- Check oil level, locating leaks if any; repair leaks, top up oil level. - Check position of manual overrides; return to normal electrical control position. - have specialist technicians check the neutral overlap time.
	11 - Selector Trolling lever not properly set	- Put the lever no trolling range

* Operations marked with this symbol should be entrusted to a ZF Authorized Service Centre.

SYMPTOMS	CAUSES	REMEDIES
8) External oil leakage	1 - Seals or shaft sealing surface worn	* - Replace seals and/or shafts
	2 - Breather blocked	- Clean or replace breather and inspect seat
	3 - Oil dipstick leaking	- Replace dipstick
	4 - Plugs and fittings loose	- Tighten all round
	5 - Pipelines damaged	- Replace pipelines
	6 - Gearcase leaking	* - Replace gaskets or sealant and torque bolts to correct setting
<hr/>		
9) Oil level fluctuating	1 - Inefficient or erratic oil/water heat exchange	* - Replace oil cooler

* Operations marked with this symbol should be entrusted to a ZF Authorized Service Centre.

Tab. 1

Annually / 500 hours	Six-monthly / 250 hours	Daily	After 50 hours operation	MAINTENANCE OPERATIONS
✓	✓	✓		Check for oil leaks
✓	✓	✓		Check oil level
✓	✓		✓	Tighten all external threaded fasteners
✓	✓		✓	Inspect suction filter
✓	✓			Clean transmission externally
✓			✓	Oil change
✓				Replace oil filter
✓				Inspect flexible coupling
✓				Inspect resilient mounts
✓				Check instruments and indicators
✓				Replace zinc anodes
✓				Service heat exchanger
	✓			Inspect electrical cables

4.2

ROUTINE MAINTENANCE OPERATIONS

4.2.1

AFTER 50 HOURS OPERATION

- **Tighten all external threaded fasteners**


- **Shift control linkage** (for Trolling Valve version)

With the engine off, remove the pin connecting the control cable to the lever of the Trolling Valve, then shift the lever to "non Trolling" position.

Select the same direction with the bridge console T.V. lever and check that the positions of the respective couplers (lever/cable) coincide.

- **Oil change**

Draw out the dipstick [1] and remove the filler plug [2] (fig 1).




Remove the drain plug [1] (fig. 2), taking care not to lose the seal, and allow the oil to run off.

Collect the spent oil in a receptacle and arrange for disposal in accordance with local environmental regulations.

Replace the plug [1] with its seal and torque to 90 Nm, then fill with fresh oil. Finally, replace the filler plug [2] (fig. 1) and torque to 80 Nm.



Having filled the gearbox and checked the level, start up the engine and run the transmission in neutral at idling speed for several minutes. Then stop the engine and check the oil level again.





• Suction filter


The oil suction filter should be inspected and cleaned after 50 hours operation, then every six months or every 250 hours, whichever is sooner.

The filter is located on the inlet side of the oil pump.

Removal procedure:

- remove the plug [1] (fig. 3);
- remove the filter [2] and the copper seal [3], clean, and refit with a new seal;
- refit the plug and torque to 100 Nm.

Fig. 3



4.2.2

DAILY

• Check for oil leaks

Start the engine and verify that there are no external leaks from fittings or other parts.

• Check oil level

The oil level must be checked only with the engine off, and at least 2 minutes after the crankshaft has stopped rotating.

The correct level is between the MAX and MIN marks on the dipstick (fig. 4).

Following the first oil change, and after carrying out repairs or servicing the filter, remember that there will be a certain amount of oil left in the heat exchanger, pipelines and filter which does not flow back into the gearcase. Accordingly, run the transmission for a few minutes, then switch off the engine, wait 2 minutes at least, and check the dipstick again.



Remove the dipstick only when the engine is off, otherwise hot oil could splash out and scald.




Fig. 4

4.2.3

AFTER SIX MONTHS OR 250 HOURS

- Check for oil leaks
- Check oil level
- Tighten all external threaded fasteners
- Inspect suction filter
- Check the electrical cables of the control box and the terminals for signs of corrosion or loose connections.

External parts of the transmission should be cleaned thoroughly, using proprietary chemicals.



Caution: do not use chemicals on rubber components.
Check that all threaded parts are tight.

- **Lubricate external moving parts**

Lubricate the moving parts of the shift linkage periodically as indicated by the manufacturer.

4.2.4**ANNUALLY OR EVERY 500 HOURS**

- **Check for oil leaks**
- **Check oil level**
- **Tighten all external threaded fasteners**
- **Inspect suction filter**
- **Clean transmission externally**
- **Lubricate external moving parts**
- **Oil change**

- **Inspect flexible coupling**

Make a chalk mark on the coupling for reference purposes, then crank the engine slowly by hand while scrutinizing rubber parts for any signs of cracking, embrittlement and overheating or oil contamination.



Caution: remove the ignition key before cranking the engine.

- **Inspect resilient mounts**

Verify the integrity of the mounts and check that they are securely anchored.

- **Check instruments and indicators**

The accuracy and reliability of these components must be checked at least once a year.

- **Replace zinc anodes**

Zinc anodes are fitted near the raw water inlet and outlet of the heat exchanger. Inspect at least once a year or every 500 hours, whichever is sooner, and replace the anodes if water has leaked.

- **Service heat exchanger**

The heat exchanger needs inspecting at least once a year and cleaning if necessary, especially in severe or abnormal operating conditions.



The identification plate fixed to the gearbox shows important information and must not be tampered with or removed; any such interference will automatically invalidate the warranty.

The details marked on the plate must be quoted in all correspondence with Service Centres.

WARRANTY

ZF PADOVA S.p.A. assumes liability, for the duration of the period specified on the warranty card, for any defects discovered in component parts of new equipment acknowledged as being attributable to substandard materials and or workmanship, whilst declining any liability for defects resulting from difficulties connected with installation or wrong operation, inexpert or insufficient maintenance and accidents. Neither is any liability assumed by ZF PADOVA S.p.A. for components such as oil seals, gaskets, drive belts, boots, guards and diaphragms or other parts in rubber which by reason of their structural composition are subject continuously to stresses and premature wear, except where the defect is indisputably attributable to the substandard fitment, application or origin of the component.

Assemblies and their component parts must be installed in accordance with ZF PADOVA S.p.A. specifications or in any event with the express approval of ZF PADOVA S.p.A. Design Engineering or Applications Department. Assemblies or parts acknowledged as being defective will be either replaced by ZF PADOVA S.p.A. or repaired at the factory or at a ZF-Service workshop, free of charge, all relative shipping costs being payable in advance by the owner of the boat or vehicle. All expenses involved in enabling ZF PADOVA S.p.A. authorized technicians to gain access to the assembly or its components parts are chargeable in full to the owner of the boat or vehicle.

ZF PADOVA S.p.A. declines any liability for damages, expenses and claims of whatever nature in connection with the warranty and will not reimburse the claimant in respect of unauthorized expenses.

In the event of repairs or modifications being carried out on the assembly or its component parts without prior approval of ZF PADOVA S.p.A. or by persons not authorized by ZF PADOVA S.p.A. or utilizing parts other than genuine ZF spares, the warranty is automatically invalidated.

In signing the attached warranty card the User agrees to comply with the foregoing terms and conditions and with the company's General Conditions of Sale.

Emergency manoeuvres when performed routinely and repeatedly will overload and/or damage the transmission. Mechanical failure resulting from this type of operation or other similar abuse can under no circumstances be considered as covered by the manufacturer's Warranty.



NOTE: THE DURATION OF THE WARRANTY IS SPECIFIED ON THE WARRANTY CARD, WHICH SHOULD BE KEPT TOGETHER WITH THE BOAT DOCUMENTS.

SERVICE CENTRES

ARGENTINA

✉ ZF FAE - FABRICA ARGENTINA
DE ENGRANAJES S.A.I. y C.

Hipolito Yrigoyen 1628 - 6° piso
1344 Buenos Aires
ARGENTINA
Tel. +54 (0)1 498 806
Fax +54 (0)1 492 517

AUSTRALIA

✉ ZF AUSTRALIA PTY. LTD.

Locked Bag 13, 23 Foundry Road
Seven Hills NSW 2147
AUSTRALIA
Tel. +61 (0)2 9674 6222
Fax +61 (0)2 9674 6445

BRAZIL

✉ ZF DO BRASIL S.A. *

Avenida Conde Zeppelin, 1935
CEP 18103-000 Sorocaba-SP
BRASIL
Tel. +55 (0)15 235 2586 / 2389
Fax +55 (0)15 235 2233

CHINA

✉ ZF SHANGHAI Representative
Office

Room 6E, Yi-Dian Building, No. 746
Zhaojiabang Road, Xuhui
District, Shanghai 200030
P.R. CHINA
Tel. +86 (0)21 6445 9745 / 9746
Fax +86 (0)21 6445 9748

✉ FOILBORN ENTERPRISE Ltd.

Unit A8-9, 13/F
Veristrong Ind. Ctr
34 - 36 Au Pui Wan. St.
Fo-tan, Shatin
N.T. Hong Kong
Tel. +852 (0)2 687 2988
Fax +852 (0)2 687 1996

✉ JEBSEN & CO LTD

12/F., Scomber Building,
1 Yip Fat Street,
Wong Chuk Hang, Hong Kong
Tel. +852 (0)2 9262179
Fax. +852 (0)2 28821588

CYPRUS

✉ CHAR. PILAKOUTAS Ltd. **

P.O. Box 1168, 7 Larnaca Road
1503 Nicosia
CYPRUS
Tel. +357 (0)2 349572
Fax +357 (0)2 349952

DENMARK

✉ ZF DANMARK ApS

Hesselager 21 - P.O. Box 97
DK-2600 Glostrup
DENMARK
Tel. +45 (0)43 436243
Fax +45 (0)43 432643

EGYPT

✉ MAPSO

5 Ahmed Orabi Street, Manshia
Alexandria
EGYPT
Tel. +20 (0)3 4833 453
Fax +20 (0)3 4833 486

FINLAND

✉ ATOY OY ATOCO

Lauttasaarentie 54
FIN-00200 Helsinki
FINLAND
Tel. +358 (0)9 6827 1
Fax +358 (0)9 6827 303

FRANCE

✉ ZF FRANCE S.a.r.l.

Z.I.
3-11 Rue Henri Poincaré
F-92 167 Antony Cédex
FRANCE
Tel. +33 (0)1 4096 4273
Fax +33 (0)1 4096 4285

GERMANY

✉ ZF MARINE GmbH *

Ehlerstrasse 50
D-88038 Friedrichshafen
GERMANY
Tel. +49 (0)7541 77 - 2207
Fax +49 (0)7541 77 - 4222

✉ ZF MARINE GmbH - ZF HURTH
MARINE **

Zamdorferstrasse 90
D-81677 München
GERMANY
Tel. +49 (0)89 930094 63/64
Fax +49 (0)89 930094 21

✉ SCHIFFSDIESELTECHNIK KIEL

Grasweg 26 b
D-24118 Kiel
GERMANY
Tel. +49 (0)431 542029
Fax +49 (0)431 542382

GREECE

✉ TEKMAR Ltd

15 Ethn. Makariou Str.
GR-185 47 Piraeus
GREECE
Tel. +30 (0)1 4820814
Fax +30 (0)1 4118938

✉ THEODOR MALERDOS & C. **

55 Dragatsaniou Street
GR-18545 Piraeus
GREECE
Tel. +30 (0)1 4172488
Fax +30 (0)1 4175441

✉ ARIEXPO ENGINEERING S.A.

60, Alimou Ave.
GR-17455 Alimos
Athens
GREECE
Tel. +30 (0)1 981 1237
Fax +30 (0)1 983 1346

INDIA

✉ BHARAT GEARS Ltd.

Hoechst House, 14 Floor
Nariman Point
Bombay 400 021
INDIA
Tel. +91(0) 22-2 83-11 14
Fax +91(0) 22-2 87-02 97

ISRAEL

✉ NIMDA CO. Ltd.

1 Korazin Street
Givatayim 53583
ISRAEL
Tel. +972 (0)3 571 2161
Fax +972 (0)3 571 5022

ITALY

✉ ZF PADOVA S.p.A. *

ZF MARINE
Via Penghe, 48
I-35030 Caselle di Selvazzano (PD)
ITALY
Tel. +39 049 8299 311
Fax +39 049 8299 550

	<p>ZF HURTH MARINE S.p.A. * Via S. Andrea, 16 I-38062 Arco (TN) ITALY Tel. +39 0464 580555 Fax +39 0464 580544</p>	SINGAPORE	<p>ZF SOUTH EAST ASIA Pte. 51 Tuas Ave. 1, Jurong Town Singapore 639501 Rep. of SINGAPORE Tel. +65 (0)8 610177 Fax +65 (0)8 621311</p>
	<p>ZF ITALIA S.r.l. Via Donizetti, 11 I-20090 Assago (MI) ITALY Tel. +39 02 4884 2778 Fax +39 02 4884 3260</p>	SOUTH AFRICA	<p>ZF of SOUTH AFRICA Pty. Ltd. P.O. BOX 2098, Kempton Park 1620 Rep. of SOUTH AFRICA Tel. +27 (0)11 453 1818 Fax +27 (0)11 453 8588</p>
JAPAN	<p>ZF JAPAN CO. Ltd. Bungakudo Bldg. 5th Flr. 1-7-1, Isago, Kawasaki-Ku Kawasaki-City Kanagawa 210 JAPAN Tel. +81 (0)44 246 3017 Fax +81 (0)44 246 3020</p>	SPAIN	<p>ZF ESPAÑA, S.A. Avenida Fuentemar, 11 E-28820 Coslada, Madrid SPAIN Tel. +34 (0)91 485 2698 Fax +34 (0)91 673 3931</p>
	<p>YOKE CO., LTD. ** Taguchi Bldg. 6F 3-16-3 Ueno, Taito-Ku Tokyo 110 JAPAN Tel. +81 (0)3 3834 2871 Fax +81 (0)3 3834 2872</p>	SWEDEN	<p>KGK TRANSMISSIONS AB Hammarbacken 8 S-191 81 Sollentuna SWEDEN Tel. +46 (0)8 923 000 Fax +46 (0)8 929 599</p>
KOREA	<p>ZF KOREA CO. Ltd. 422-2 Chongchon-dong Bupyeong-Gu, Incheon 403-032 Rep. of KOREA Tel. +82 (0)32 505 1530 Fax +82 (0)32 505 1514</p>	TURKEY	<p>NIVEKO Makina Ticaret Limited Takkeci Sokak No. 3 TR-80820 Arnavutköy - Istanbul TURKEY Tel. +90 (0)212 287 2780 Fax +90 (0)212 287 6571</p>
	<p>ZF-HURTH MARINE KWANG-NAM 10FI Hyundai Bldg. 80 Jeok Sun-Dong Jong Ro-KU - Seoul Rep. of KOREA Tel. +82 (0)32 738 0151 Tel. +82 (0)32 738 0158</p>	UNITED KINGDOM	<p>ZF GREAT BRITAIN Ltd. Abbeyfield Road, Lenton Nottingham NG7 2SX UNITED KINGDOM Tel. +44 (0)115 986 9211 Fax +44 (0)115 986 9261</p>
MALAYSIA	<p>AJENSI TULEN SDN. Bhd. 35 A Jalan Anggerek 36 Taman Johor Bahru, Johor MALAYSIA (WEST) Tel. +60 (0)7354 7755 Fax +60 (0)7354 7757</p>	UNITED ARAB EMIRATES	<p>ZF MARINE MIDDLE EAST Office No. 16 Main Office Block Lamnalco Oilfield & Marine Supply Base Creek Road, Sharjah U.A.E. Tel. +971 6 5722 455 Fax +971 6 5741 745</p>
MALTA	<p>LANCING MARINE 9, Main Street Zurriq MALTA Tel. +356 (0)6 82244 Fax +356 (0)6 11223</p>	U.S.A.	<p>ZF INDUSTRIES INC ZF MARINE U.S. HEADQUARTERS * 3131 Southwest 42nd Street Fort Lauderdale, FL 33312 U.S.A. Tel. +1 954 581 4040 Fax +1 954 581 4077 (SERVICE / PARTS) Fax +1 954 581 4078 (SALES)</p>
NETHERLANDS	<p>AMW MARINE Veersedijk 99 NL-3341 LL Hendrik-Ido Ambacht THE NETHERLANDS Tel. +31 (0)78 6810100 Fax +31 (0)78 6818878</p>		<p>ZF INDUSTRIES INC. ZF MARINE GULF COAST FACILITY 161, James Drive West, Suite 120 St. Rose, LA 70087 U.S.A. Tel. +1 504 443 0501 Fax +1 504 443 0504</p>
	<p>DACO B.V. ** Avelingen - West 30 NL - 4202 MS Gorinchem THE NETHERLANDS Tel. +31 (0)183 637577 Fax +31 (0)183 632906</p>		<p>ZF INDUSTRIES INC: ZF MARINE WEST COAST BRANCH 1095 Andover Park East, Seattle, WA 98188 U.S.A. Tel. +1 206 574 0375 Fax +1 206 574 0868</p>
NORWAY	<p>ZF NORGE AS Casper Storms Vei 19 N-0664 Oslo NORWAY Tel. +47 (0)22 720 575 Fax +47 (0)22 720 902</p>		
POLAND	<p>MARCO MOTORS ul. Lady 2 PL-71-605 Szczecin POLAND Tel. +48 (0)91 4500552 Fax +48 (0)91 223942</p>		

* MANUFACTURING LOCATIONS
** ZF HURTH REPRESENTATIVE

Hours work

Date, stamp, signature

Hours work

Date, stamp, signature

Hours work

Date, stamp, signature

Hours work

Date, stamp, signature

**ZF Marine GmbH**

D-88038 Friedrichshafen

GERMANY

Phone +49 (7541) 77-2207

Fax +49 (7541) 77-4222

ZF Padova S.p.A.

Via Penghe, 48
I-35030
Caselle di Selvazzano (PD)

ITALY

Phone +39 - 049 8299-311

Fax +39 - 049 8299-550

ZF-HURTH Marine S.p.A.

Via S. Andrea, 16
I-38062 Arco (TN)

ITALY

Phone +39 - 0464 580-555

Fax +39 - 0464 580-544

ZF do Brasil S.A.

Avenida Conde Zeppelin, 1935
Cep. 18103-000 Sorocaba - SP

BRASIL

Phone +55 (15) 235 2586/2389

Fax +55 (15) 235 2233

Plus d'informations sur : www.dbmoteurs.fr